
Ångström Manual

– *Embedded Power* –

MERCIADRI¹ LUCA, KOËN² KOOI

June 29, 2010

¹Luca.Merciadri@student.ulg.ac.be

²k.kooi@student.utwente.nl

Contents

Thanks	1
License	2
I History	3
II Installation	5
1 Warnings	6
2 Installation options	7
3 Loopback Image	8
3.1 Use	8
3.2 Interest	8
4 LiveRam Disks	10
4.1 Interest	10
4.2 The Linux Boot Process	10
4.3 Easy Versions	11
4.4 Hard Versions	11
4.4.1 In Theory	11
4.4.2 In Practice	12
4.4.2.1 The Python Script	12
4.4.2.2 The Outfile	13
4.4.2.3 HaRET	13
4.4.2.4 zImage	13
4.4.2.5 Initrd	13
4.4.2.6 The Startup Script	13
4.4.2.7 Automatizing The Task	13
4.4.3 Summary	14
4.5 Kexecboots	15
4.5.1 Credits	15
4.5.2 Building	15
4.5.2.1 Overriding the Default Version	15
4.5.2.2 Remarks	16
4.5.3 Role	16

4.5.4	Way of Work	17
4.5.5	Consequences	17
4.5.6	Screenshots	17
5	Diff. Img. for Diff. Purp.	19
5.1	Formats	19
6	Hardware	21
6.1	Supported Devices	21
6.1.1	Installation Procedure	21
6.1.2	List	22
7	After Installation	24
7.1	First Steps	24
7.1.1	Security Before Everything	24
7.1.2	Internationalization and Localization	24
7.1.2.1	Two Main Definitions	24
7.1.2.2	Locale and Packages	25
8	Bug Tracking System	26
III	Building	27
IV	The Ångström System	30
9	Introduction	31
10	Packaging System	32
10.1	Introduction	32
10.2	Core Principle	32
10.3	Commands	33
10.4	Selecting Packages	34
10.5	Format of Packages	34
10.6	Sw. fr. Cons. Img. to X Serv.	34
11	Use	35
11.1	The User	35
11.2	Checking the Version	35
11.3	Global Networking	35
11.3.1	Basic Info	35
11.3.2	With USB	36
11.3.2.1	On the Server	36
11.3.2.2	On the Slave	37
11.3.3	With Bluetooth	38
11.3.4	With WiFi	39
11.3.4.1	Preliminaries	39
11.3.4.2	Commands	40

11.3.4.3	WEP	40
11.3.4.4	WPA	40
11.3.4.5	Drivers	41
11.3.5	Firewall	41
11.4	Errors You Could Encounter	41
12	Getting More Help	42

Thanks

I (Luca Merciadri) would sincerely want to thanks **Andrea Adami** for his information about kexec-stuff, **Yuri Bushmelev** for his details on kexec-stuff, **Gregory Graeme** for his first answer, **Kooi Koen** for his idea of setting up a seperate git repo on the Ångström site or gitorious, and modifying it slightly, **Lex Landa** for his investment about hx4700, and for his precious help (in particular: Section [10.2](#), p. [32](#), Subsections [4.5.1](#), [4.5.2](#), [4.5.2.1](#), resp. [15](#), p. [15](#), p. [15](#)), **Kelly Price** for his info about the kexecboot kernels.

THE Angström Manual is under Creative Commons (CC) BY-SA license. In this, *BY* and *SA* globally mean ([3, 4]) that others can remix, tweak, and build upon our work, even for commercial reasons, as long as others credit us and license their creations under the identical terms. All new works based on this will carry the same license, so any derivatives will also allow commercial use.

You are thus **free to**

1. *share*: copy, distribute and transmit the work,
2. *remix*: adapt the work

under the following assumptions:

1. You must attribute the work in the manner specified by Luca Merciadri,
2. If you alter, transform, or build upon, this work, you may distribute the resulting work only under the same, similar or a compatible license.

Any of the above conditions can be waived if you get permission from Luca Merciadri, as Luca Merciadri holds the copyright.

In no way are any of the following rights affected by the license:

- Your fair dealing or fair use rights,
- The author's moral rights,
- Rights other persons may have either in the work itself or in how the work is used, such as publicity or private rights.

For a more detailed description of the license, please read

<http://creativecommons.org/licenses/by-sa/3.0/legalcode>.

If you need further information about this, please **contact me**.

© Merciadri Luca 2009. Please see Page 1 for thanks.

Part I
History

Ångström was started by a small group of people who worked on the OpenEmbedded, OpenZaurus and OpenSimpad projects to unify their effort to make a stable and user-friendly distribution for embedded devices like handhelds, set top boxes and network-attached storage devices and more.

OpenEmbedded is used by Ångström but Ångström is *not* OpenEmbedded Ångström.

Part II

Installation

BEFORE beginning to speak about Ångström, here are some problems you could encounter when trying it:

1. Installing Ångström could result in a bricked device, with the consequences of this: your device could be completely unuseful.
2. Modifying the internal configuration of your device voids warranty.
3. Trying Ångström on older PocketPC, Windows Mobile and Windows CE devices is not without any danger: it erases the content of the RAM. If you want to exit Ångström, you are obliged to proceed to a hard-reset. The result of this hard-reset is that you lose all your personal data, programs, *etc.* After hard-resetting your device, you will find your system, in the same state as when you first booted your device after having bought it.

These things being said, enjoy reading this, and try Ångström on your embedded device!

FOR a given device, there are different possibilities to try Ångström on it:

1. **Using the internal flash memory.** This method is potentially dangerous, as it could result in a bricked device.
2. **Using external storage.** Running Ångström of an SD or CF card is relatively safe
3. **Using a loopback image.** Like the external storage option, but using a monolithic file.
4. **Using a liveram disk.**

These options are highly device dependent, so the instructions are broken down per device group.

Contents

3.1 Use	8
3.2 Interest	8

3.1 Use

ACCORDING to [6] and to my tests, the use of a *loopback image* for Ångström is done by following these steps:

1. Once you are in <http://www.angstrom-distribution.org/releases/2007.12/images/>,
2. Download two files:
 - (a) a `.img.bz2` one;
 - (b) a `.exe` one,
3. Place them on an extension card, in the same (root) directory,
4. Launch from your OS the `.exe` file,
5. Choose the `.img.bz2` image once Ångström will have asked you which image it should use, by
 - (a) Navigating between images with the “physical” arrows of your device (if so),
 - (b) Pressing between the four “physical” arrows of your device (to confirm, if so).

3.2 Interest

Once these steps have been performed, Ångström will be *executed*. If you choose to read the image from your extension card (and it should be so), all the things you will modify under Ångström (*i.e.* new sessions, *etc.*), will be written on the extension card.

Consequently, even if you hard-reset the device, doing all the given steps will, if you have already tried Ångström at least once, using the same extension card as the one you are using now, let you use the session you defined, all your parameters being written in the memory of your extension card.

Contents

4.1	Interest	10
4.2	The Linux Boot Process	10
4.3	Easy Versions	11
4.4	Hard Versions	11
4.5	Kexecboots	15

4.1 Interest

LiveRam Disks is an interesting way to try Ångström without any great danger¹ (as you only lose personal data and programs, *i.e.* internal configuration). However, all the changes you will do will *not* be kept.

A LiveRam Disk is simply a `.exe` file which can be executed from the File Explorer of your Windows Mobile Edition.

It should be clear in your mind that these LiveRam Disks are less interesting for the developers; as a result, they are less “up-to-date.” If you want to use up-to-date LiveRam Disks, you will have to do some tricky things which will be given in 4.4, p. 11.

We shall give the important info about these two possibilities. To simplify the presentation, we shall denote by “easy version” a version which is directly available on a website, and which is ready to execute, on the opposite of “hard versions,” whose file is the result of a compilation of different files.

We begin by a rough explanation about how Linux boots.

4.2 The Linux Boot Process

The *Linux boot process* is simple [10]:

¹More info about this at Chapter 1, p. 6, point ??.

1. A boot loader finds the kernel image on the disk, loads it into memory, and starts it,
2. The kernel initializes the devices and its drivers,
3. The kernel mounts the root filesystem,
4. The kernel starts a program called `init`,
5. `init` sets the rest of the processes in motion,
6. The last processes that `init` starts as part of the boot sequence allow you to log in.

4.3 Easy Versions

The *easy versions* date back to the year 2007. A `hx4700` version can be found² with the name `Angstrom-x11-image-liveramdisk-2007.12-hx4700.exe`

You simply use such a file by launching it in the WM File Explorer. That is really straightforward.

4.4 Hard Versions

The *hard versions* are as up-to-date as you expect them to be, because you constitute them. After having spoke with Lex Landa because of a WiFi problem, some info emerged from this thread³, becoming increasingly big.

4.4.1 In Theory

To build this `exe` file, there is a Python script. It is called `make-bootbundle.py`. Its usage is described by:

```
make-bootbundle.py -o <outfile> <path to haret.exe> <zImage> <initrd> <script>
```

Let's describe these elements in their order:

1. `make-bootbundle.py`: the Python script.
2. `<outfile>`: the name of the file you will launch in the WM File Explorer.
3. `<haret.exe>`: the name of the HaRET bootloader.
4. `<zImage>`: the kernel.
5. `<initrd>`: the `initrd`.
6. `<script>`: the startup script.

To understand what they mean, you need some basic knowledge in Linux/UNIX systems which will not be detailed here. That is a prerequisite.

²In the <http://www.angstrom-distribution.org/releases/2007.12/images/hx4700/> directory.

³(See <http://www.mail-archive.com/angstrom-distro-users@linuxtogo.org/msg02710.html>.)

4.4.2 In Practice

Practically, you may wonder how all these files can be found, as, even with some searches on the Internet, you may still be wondering where they are.

4.4.2.1 The Python Script

You can use the following Python script (thanks to Lex Landa for this):

```
#!/usr/bin/env python

import sys
import os
import stat
import struct
import getopt
import re

optlist, args = getopt.gnu_getopt(sys.argv[1:], "o:vh?")
opts = {}
opts.update(optlist)

if len(args) != 4:
    print "make-bootbundle - Make a standalone HaRET boot bundle with kernel and initrd"
    print "Usage: make-bootbundle.py -o <outfile> <path to haret.exe> <zImage> <initrd> <script>"
    sys.exit(0)

outfile = opts["-o"]

os.system("cat %s %s %s %s> %s" % (args[0], args[1], args[2], args[3], outfile))

exe = open(outfile, "r+b")
kernelSt = os.stat(args[1])
initrdSt = os.stat(args[2])
scriptSt = os.stat(args[3])

exe.seek(0, 2)
exe.write("HARET1\0\0")
exe.write(struct.pack("i", kernelSt[stat.ST_SIZE]))
exe.write(struct.pack("i", initrdSt[stat.ST_SIZE]))
exe.write(struct.pack("i", scriptSt[stat.ST_SIZE]))
exe.write(struct.pack("i", 0))
exe.write(struct.pack("i", 0))
exe.write(struct.pack("i", 0))
exe.close()

if opts.has_key("-v"):
    haretSt = os.stat(args[0])
    print "HaRET:\t", haretSt[stat.ST_SIZE]
    print "Kernel:\t", kernelSt[stat.ST_SIZE]
    print "Initrd:\t", initrdSt[stat.ST_SIZE]
    print "Script:\t", scriptSt[stat.ST_SIZE]
    print "Header:\t", 8 + 4*6
    print "-----"
    print "Total:\t", \
        haretSt[stat.ST_SIZE] + kernelSt[stat.ST_SIZE] + \
        initrdSt[stat.ST_SIZE] + scriptSt[stat.ST_SIZE] + 8 + 4*6
```

4.4.2.2 The Outfile

There is nothing to say about the *outfile*, except that giving it a representative name is a nice thing. For this, you may use the script given at point 4.4.2.7, p. 13.

4.4.2.3 HaRET

The *HaRET* bootloader is already an old thing: it was also used in Familiar. The latest one⁴ is `haret-0.5.2.exe`.

4.4.2.4 zImage

The easiest thing is to use the Narcissus image generator⁵ from Ångström's website. It will generate a file like⁶ `hx4700-full-x11-image-hx4700.tar.bz2` for the `hx4700`. You then go to its folder named `boot`, and extract the corresponding `zImage`. For example, it is here `zImage-2.6.21-hh20`. Its numbering is the kernel's numbering, as the `zImage` is the kernel.

4.4.2.5 Initrd

The `initrd` file is under the form of a `.cpio.gz`. For example, its current name is `initramfs.cpio.gz`.

You can use the following bash script to make the `initrd` (thanks to Lex Landa for this):

```
#!/bin/sh
# Execute this from the initrd root dir.
su
find . | cpio -o -H newc | gzip -9 > ../initramfs.cpio.gz
```

4.4.2.6 The Startup Script

You can use the following *startup script*:

```
# initramfs-bootmenu HaRET script
# (c) 2007 Paul Sokolovsky
msgbox "Attention!" "This will boot Linux. All memory will be overwritten and hard reset will be
required to return to Windows Mobile.
You *MUST BACKUP* your data first. Continue booting (Cancel - quit to make backup)?" 0x40031
if result == 2 exit
set cmdline "root=/dev/ram0 rootdelay=3
ip=192.168.2.202:192.168.2.200:192.168.2.200:255.255.255.0:ipaq:usb0
console=tty0 console=ttyS0,115200n8 rdinit=/sbin/init"
ramboot
```

It is named `startup.txt.bootimage` in our example.

4.4.2.7 Automatizing The Task

If you want to make the task of producing the bootbundle more automatic, you can use the following bash script (thanks to Lex Landa for this):

⁴Which can be found in the <http://handhelds.org/~koconnor/haret/> directory.

⁵That you can find at <http://www.angstrom-distribution.org/narcissus/>.

⁶The name of this file has actually be decided only by me, but it represents the content of it.

```
#!/bin/sh

# Run this to build the boot bundle
# L. 01-Nov-09

dt="'date +%d%m%y-%H%M%S' "

./make-bootbundle.py -o bootbundle-${dt}.exe haret-0.5.2.exe
zImage-2.6.21-hh20 initramfs.cpio.gz startup.txt.bootimage
```

What it actually does is use the predefined files, and give a date-related name to the boot bundle file (*i.e.* the `.exe` that you will execute from the WM File Explorer).

You can evidently modify it as you want.

4.4.3 Summary

You will find here a summary of all these files. I suggest you to download them at the place of copying the code of this booklet, as, for Python scripts, indentation is important, and it could be broken by the output of this document.

File	Role	Download at
<i>Python script</i>	Produce the bootbundle	http://www.student.montefiore.ulg.ac.be/~merciadri/angstrom/files/make-bootbundle.py
<i>Outfile</i>	The bootbundle	http://www.student.montefiore.ulg.ac.be/~merciadri/angstrom/files/console-zImage-2.6.21-hh20-hx4700.ex
<i>HaRET</i>	The bootloader	http://handhelds.org/~kocconnor/haret/haret-0.5.2.exe or http://www.student.montefiore.ulg.ac.be/~merciadri/angstrom/files/haret-0.5.2.exe
<i>zImage</i>	The kernel	http://www.student.montefiore.ulg.ac.be/~merciadri/angstrom/files/zImage-2.6.21-hh20
<i>initrd</i>	The initrd	http://www.student.montefiore.ulg.ac.be/~merciadri/angstrom/files/initramfs.cpio.gz
<i>Startup script</i>	The startup script	http://www.student.montefiore.ulg.ac.be/~merciadri/angstrom/files/startup.txt.bootimage

Table 4.1: The different files for the “Hard version.”

If you use such a LiveRam Disk, Linux should boot in something like 10 seconds.

4.5 Kexecboots

4.5.1 Credits

Yuri Bushmelev, Thomas Kunze and Matthew Allum are the authors of the kexecboot.

4.5.2 Building

The OpenEmbedded (<http://www.openembedded.org>) system is used to build kexecboot. Please see the “Getting Started” for this, for example at

http://wiki.openembedded.net/index.php/Getting_started

document for instructions when setting up OpenEmbedded. Please ensure that you have updated your OpenEmbedded tree recently (do

```
git pull
```

from the openembedded / directory).

4.5.2.1 Overriding the Default Version

The default kexecboot version can be overridden by specifying a BitBake recipe file (.bb) when invoking bitbake, or by setting the variable `PREFERRED_VERSION_linux-kexecboot` in `local.conf`, according to [1], for example with

```
bitbake linux-kexecboot -b \  
  ../openembedded/recipes/kexecboot/linux-kexecboot_2.6.32.bb
```

for 2.6.32. This will build kexecboot with a 2.6.32 kernel. Depending on the options specified in `conf/local.conf`, the kexecboot files may be written in a variety of formats.

There are other kexecboot recipe files, such as (2010):

```
initramfs-kexecboot-image.bb  
kexecboot-cfg_0.1.bb  
kexecboot_git.bb  
linux-kexecboot_2.6.21-hh20.bb  
linux-kexecboot_2.6.24.bb  
linux-kexecboot_2.6.26.bb  
linux-kexecboot_2.6.29.bb  
linux-kexecboot_2.6.32+2.6.33-rc3.bb  
linux-kexecboot_2.6.32.bb
```

More specifically, the bitbake process consists of downloading and building the cross-compiler toolchain, native toolchain and kernel, and building the cpio-format initramfs image (`linux-kexecboot-image`) for the kexecboot system. This image is used as a ramdisk-based root filesystem, and its purpose is to mount one or more filesystems, locate the replacement kernel (and root filesystem) and call the kexecboot kernel routine to replace the kernel.

Before the kernel is built, any patches are downloaded and applied, depending on the machine type which is selected. The kernel image is compressed and written, along with the initramfs filesystem.

The kexecboot kernel's command line arguments are set in the default recipe file, *i.e.* `recipes/kexecboot/linux-kexecboot.inc`. The `CMDLINE` variable is set conditionally, depending on the platform (`any`, `poodle`, `akita`, `collie`, `spitz` and `hx4700`). The default kernel configuration is read from file `defconfig` and in the `do_configure_append()` section, some edits are made to remove various configure options, and add others. `CONFIG_BLK_DEV_INITRD` and `CONFIG_KEXEC` are enabled, and the `initramfs` source file is set to `initramfs.cpio.gz`. Kernel modules are disabled and the kernel is built with the configuration in file `.config`.

The `require` line in `linux-kexecboot.inc` includes `../linux/linux.inc`, which builds the kexecboot kernel. Conditional tests decide whether OABI or EABI support should be included, set the Linux logo type, Thumb instruction set support, endianness and other options.

The kernel name is set with the following lines:

```
KERNEL_IMAGE_BASE_NAME = "${KERNEL_IMAGETYPE}-kexecboot-${PV}-${PR}-${MACHINE}"
KERNEL_IMAGE_SYMLINK_NAME = "${KERNEL_IMAGETYPE}-kexecboot-${MACHINE}"
```

*Where is KERNEL_IMA
set?*

The `do_stage()` and `do_install()` steps are set to empty functions, meaning that they will have no effect: the kernel and `initramfs` are built only, and no other actions occur. The generated images will be written in various locations

Which locations?

For example, `build/tmp/depoy/glibc/images/c7x0/` dir contains:

```
Angstrom-initramfs-kexecboot-image-glibc-ipk-2009.X-test-20100106-c7x0.rootfs.cpio.gz
Angstrom-initramfs-kexecboot-image-glibc-ipk-2009.X-test-20100106-c7x0.rootfs.cpio.lzma
initramfs-kexecboot-image-c7x0.cpio.gz -> Angstrom-initramfs-kexecboot-image-glibc-ipk-2009.X-test-20100106-c7x0.rootfs.cpio.gz
initramfs-kexecboot-image-c7x0.cpio.lzma -> Angstrom-initramfs-kexecboot-image-glibc-ipk-2009.X-test-20100106-c7x0.rootfs.cpio.gz
modules-2.6.26-r12-c7x0.tgz
zImage-2.6.26-r12-c7x0.bin
zImage-c7x0.bin -> zImage-2.6.26-r12-c7x0.bin
zImage-kexecboot-2.6.26-r15-c7x0.bin
zImage-kexecboot-2.6.32-r15-c7x0.bin
zImage-kexecboot-c7x0.bin -> zImage-kexecboot-2.6.32-r15-c7x0.bin
```

If `USE_MACHINE_KERNEL` is defined when building kexecboot, `/proc/cpuinfo` is scanned for a `Hardware:` line and if present, the `Hardware` result is converted to lower case, spaces are replaced with underscores and `/mnt/boot/zImage-` is prepended to it. For example, in the case of the Sharp SL-5500 ('Collie'), `/proc/cpuinfo` has the line

```
Hardware      : Sharp-Collie
```

The line is checked for a colon and if found, `Sharp-Collie` would be appended to the `zImage-` string, so `/mnt/boot/zImage-Sharp-Collie` is looked for.

4.5.2.2 Remarks

4.5.3 Role

A *kexecboot kernel* is, in a more precise way, a kernel that has the kexec feature called; this feature can load other, normal kernels in and boot into them. This allows the main kernel used in Ångström to be upgraded without flashing the device whole. The kexecboot kernel needs to be small and slim enough that it can fit into the NAND, yet be able to handle the managing RAM initdisk used to find and select the new kernel to boot off of. It should also (in minimal variant) have support all 'bootable' storages (NAND, CF, SD/MMC, etc).

Similar projects include "Two Kernel Monte" and CoreBoot.

Kexecboot development was started to solve following problems:

1. Zauruses with default bootloader and MTD partitioning have only 1.2 Mb of free space in NAND to hold kernel. Modern kernels are too big to fit into that constraints without significant loss in features (even with separate modules),
2. Some devices (such as Zauruses) have no possibility to boot from other media (SD/MMC/CF) with default bootloader.

Ångström was based on top of OE (OpenEmbedded), OpenZaurus and OpenSimpad. Zaurus' OS was the most supported platform, at that times. To address these problems, Thomas Kunze wrote first versions of kexecboot.

4.5.4 Way of Work

When kexecboot's kernel is loaded, it runs kexecboot binary as init process. This process does the following things (for the current development version, *i.e.* 0.6):

1. scan all known partitions on devices (from `/proc/partitions`),
2. check that the partition's filesystem is known (according to `fstype.c` from `klibc` and `/proc/filesystems`),
3. mount that partition and check for `/boot/boot.cfg` there:
 - (a) if `boot.cfg` is found, then parse it and do some additional things (load custom icon for example);
 - (b) if `boot.cfg` is not found, then check for default kernels (`/boot/zImage`, `/zImage`),
4. check for `zImage`, the replacement Linux kernel (compressed),
5. create and show GUI with collected partitions,
6. wait for selection and then kexec selected kernel.

Kexecboot binary can be started as non-init process too, so you can run it in your own image at any time too.

Latest kexecboot release was 0.5. The development version is 0.6.

4.5.5 Consequences

As the kexecboot kernel embeds a very limited initramfs, it contains just a couple of static binaries (kexec and kexecboot). Kexec is the tool (see `kexec-tools`), kexecboot is the "init," a custom-purposed binary launching kexec with appropriate args. The name "kexecboot" was given by the author of the project.

So, if you want to create a standard "liveramdisk" image, just enable kexec during the config of the kernel and deploy `kexec-tools` in your image.

4.5.6 Screenshots

Here are pictures (taken from [2]) of a v0.4 *kexecboot*.

(a)
New
portable
partitions
from
f6ad.
card.

Figure 4.5.1: Kexecboots' screenshots.

Different Images for Different Purposes

ACCORDING to [5], there are different types of images. They are represented at Table 5.1.

Name	Description
base-image	Very minimal system without GUI. SSH login over built-in networking (usbnet, ethernet port, ...). This is intended for headless devices with very small amount of flash (like routers) or for special-purpose installs (such as standalone portable servers, automation controllers, data loggers, etc.).
console-image	Usable system without GUI. Can connect to net via BT/WiFi/USB. Should handle devices connected via CF or USB Host.
minimal-gpe-image	Very minimal system with X11 GUI, on which you may install software you need. Suitable for devices with minuscule amount of flash and for DIY fans. NOT suitable for first-time users.
x11-image	Like console-image but with X11 environment.
x11-gpe-image	x11-image with GPE PIM suite preinstalled.
x11-pimlico-image	x11-image with OpenedHand Pimlico PIM suite preinstalled (VGA screen is recommended).
x11-office-image	x11-image with GNOME Office preinstalled (Abiword, Gnumeric, etc.).

Table 5.1: Different types of images for Ångström, for different purposes.

Images like x11-gpe and big are provided for selected devices which come with large secondary storage (like Microdrives). If there are no such images for your device, you do not lose anything: you can easily install any software you need from the feeds.

If you are in doubt which image to choose, use x11-image: it is intended as a starting point for majority of users, offering basic GUI tools to control the device and devoid of application software which not every user may need, thus offering good compromise between usability, size required, and free space available.

5.1 Formats

There are also *different formats* for each image. They are summarized at Table 5.2.

Extension	Description
.tar.gz, .tar.bz2, .cpio.gz	Archived root filesystem (rootfs), suitable for installing to a secondary storage by simply unpacking (the secondary storage must be already formatted appropriately, usually with ext2 filesystem)
.ext2, .ext2.bz2, .img, img.bz2	Integral filesystem image, which can be copied (<i>e.g.</i> using dd) to a secondary storage partition directly.
.jffs2	Flash image, which can be flashed to internal flash ROM of the specific device
.summary.jffs2	Same as .jffs2, but with extended “summary” information allowing to mount flash filesystem quicker. (Suggested if space allows.)
.exe	Executables for WinCE devices. Bigger files are LiveRam Disks, Smaller files are bootmanagers (see Chapter 3, p. 8)
zImage	Standalone kernel image for ad-hoc boot-loaders

Table 5.2: Different formats of images for Ångström, for different purposes.

UNFORTUNATELY, embedded devices vary greatly in their architecture and system software, and as of now, no generic installation procedure suitable for all of them is available.

6.1 Supported Devices

6.1.1 Installation Procedure

Here are the devices which are known to be supported:

1. **Sharp Zaurus family**

- (a) *kexecboot*: For the Zaurus, a special “kernel+initramfs” has been developed. This special-purpose kernel is small enough to be flashed on NAND and features a framebuffer graphical menu for the selection of boot media containing the kernel to be kexec’ed. Multi-partition cards and lots of filesystems are supported. The kernels to be launched are searched for in /boot of each available partition. There is also a configuration file (/boot/boot.cfg) which allows selection of other kernels, custom kernel command lines, and specifies the label and the icon for each instance;
- (b) *How to install*: Just unpack zaurus-installer-YOURMACHINE.tar.gz on a free (FAT or EXT2/3 formatted) partition: the package contains the kexecboot-kernel and the updater.sh utility. Then proceed as usual for flashing (switch off, pull battery out, insert battery again, before inserting AC plug, press OK and Power On. In the Japanese Menu select “4” and finally “3” for SD card or “4” for CF). See Figure 6.1.1 for a screenshot;
- (c) *For the SL-5500 (collie)* and optionally for other Zaurus too, flashing is possible just using the routines of the original firmware: reset the unit, Press “C” and “D” buttons during restart. That is specialized. For this, please read <http://linuxtogo.org/gowiki/CollieInstall>;
- (d) If you want a **rootfs in NAND**, this must be in the .jffs2 format. Just rename your-image-rootfs.jffs2 to initrd.bin and copy it on the card with updater.sh. The image will be flashed on mtd2,

2. **Sharp Zaurus family (old method, kernel in NAND).** Please follow the following links, according to your device:
 - (a) *Sharp Spitz (c3xxx)*: <http://www.angstrom-distribution.org/angstrom-installation-spitz>;
 - (b) *Sharp Akita (c1000)*: <http://www.angstrom-distribution.org/c1000-install-instructions>;
 - (c) *Sharp Corgi, Shepherd, Husky, Boxer (c7x0-c8x0)*: <http://www.angstrom-distribution.org/zaurus-c7x0-c8x0>;
 - (d) *Sharp Collie (SL-5500)*: <http://linuxtogo.org/gowiki/CollieInstall>;
 - (e) *Sharp Poodle (SL-5600)*: <http://linuxtogo.org/gowiki/PoodleInstall>;
 - (f) *Sharp Tosa (SL-6000)*: <http://linuxtogo.org/gowiki/TosaInstall>,
3. **PocketPC and Windows Mobile family,**
4. **Generation6 devices** such as Archos 5 and Archos 7.

Figure 6.1.1: Sharp Zaurus family's screen.

6.1.2 List

Roughly speaking, the following devices are supported:

1. Acer n50,
2. Beagle Boards,
3. Dell Axim X50/X51,
4. HP's
 - (a) h1940;
 - (b) h2200, but you may read this: <http://www.angstrom-distribution.org/ipaq-h2200-series>;
 - (c) h3900;
 - (d) h4000;
 - (e) h63xx;
 - (f) hx2000;
 - (g) hx4700 (one of the devices amongst the most supported ones);
 - (h) rx1950;
 - (i) rx3000;
 - (j) rx3115,
5. HTC Alpine, Apache, Athena, Beetles, Blueangel, Magician, Titan, Universal,
6. iMate Jasjar,
7. Nokia 770 internet tablet, and N800 (but see <http://linuxtogo.org/gowiki/AngstromAndN800>),

8. Pandora Handheld (see <http://openpandora.org/>).

The h2000 create random problems because of WM 2005. See <http://www.handhelds.org/hypermail/hx2000-port/0/0083.html> and <http://www.handhelds.org/hypermail/hx2000-port/0/0085.html> for this. If your device is listed here: <http://linuxtogo.org/gowiki/0eDeviceList> or here: <http://linuxtogo.org/gowiki/LinuxDevices>, there may be chances that it works, as this project is closely related to OpenEmbedded.

7.1 First Steps

7.1.1 Security Before Everything

ONCE you have installed Ångström and booted into the system, you are highly recommended to upgrade system from the feed to get the latest security and bug fixes since the release has been made. To do this, you need to run the following commands in terminal:

```
opkg update
opkg upgrade
```

However, for this to work, you must be connected to the Internet to be able to download updates. For more info about the package manager, please have a look at Chapter 10, p. 32.

You may also check the packages of Ångström's repositories at <http://www.angstrom-distribution.org/repo/>.

7.1.2 Internationalization and Localization

7.1.2.1 Two Main Definitions

Here are two definitions from [5]:

1. *Internationalization* (i18n): Having support in the system for different character sets (both for input and output), fonts, and using well-known locale-neutral standards for representing data like time/date, and numbers,
2. *Localization* (l19n): Having support in the system for particular locality, from time and monetary data to messages output by applications.

Ångström is targetted at the wide user community throughout the world, and consequently provides good i18n and l19n support, with basic i18n support available out of the box with standard X11 GUI images. As a contemporary Linux system, Ångström uses UTF-8 encoding. Ångström's images come with English UTF-8 locale (en_GB) which is suitable to get good i18n support. Make sure that you select "English(Great.Britain)" when logging into X11 session. You select the locale for

session when logging into X, “Language” dropdown. After Ångström install, it will contain two choices: “English(C locale)” (just “English” in older builds) and “English(Great_Britain).” Make sure you avoid “English(C locale)” as it does not actually offer any i18n, limiting used charset to ASCII.

To get further regarding i18n support than generic i18n above, one needs to configure proper locale for libc(C runtime library). As said earlier, Ångström’s images come with en_GB locale preinstalled (and this was apparently not the best choice, as most people would expect en_US to be default-available).

To install more libc locales, use packages with names locale-base-LL-VV, where LL is the language code and VV is the variant code, both converted to lowercase. For example, you may use

```
opkg install locale-base-en-us
```

Once the package has been installed, a new choice will be available in X11 login.

Some bugs are known with the Shell and the encodings.

7.1.2.2 Locale and Packages

If you want *some given packages to be in your language*, you must install locale for the corresponding language. Then, for each application you are interested in, you should install package <app>-locale-LL to get translated messages, where LL is the language code, as stated before.

CHAPTER 8

Bug Tracking System

For the *bug tracking system*, please use BugZilla (<http://bugs.openembedded.org/>). That is the easiest way to solve problems together.

Part III
Building

ALL Ångström images are built using OpenEmbedded. We here describe the steps (coming from [8]) which are necessary to setup an environment where you can build images and packages yourself. You may find more info for the needed packages on your host and possible tweaks (SElinux, ...) at [9].

Here are the steps you need to do:

1. **Get OE metadata.** Use

```
export OETREE="${HOME}/OE"
mkdir -p ${OETREE} && cd ${OETREE}
git clone git://git.openembedded.org/openembedded.git openembedded
cd openembedded
git checkout origin/stable/2009 -b stable/2009
```

2. **Update OE metadata.** Use

```
cd ${OETREE}/openembedded
git pull
```

3. **Setup the environment.**

(a) Download

<http://www.angstrom-distribution.org/files/source-me.txt>

to \${OETREE};

(b) Setup local.conf for our needs:

```
mkdir -p ${OETREE}/build/conf
cp ${OETREE}/openembedded/contrib/angstrom/local.conf ${OETREE}/build/conf/
```

Optionally, you can open \${OETREE}/build/conf/local.conf in your favourite editor and add:

```
MACHINE ?= "<your machine>"
```

where

```
"<your machine>"
```

is replaced with the machine you want to build for, such as

- i. beagleboard for the OMAP3 beagleboard.org board,
- ii. c7x0 for pxa25x zaurus clamshells (SL-C700, SL-C750, SL-C760, SL-C860, SL-7500),
- iii. spitz for pxa27x zaurus clamshells with a microdrive (SL-C3000, SL-C3100, SL-C3200),
- iv. akita for pxa27x zaurus clamshells without a microdrive (SL-C1000),
- v. tosa for the SL-C6000,
- vi. h2200 for the iPAQ h2200 series,
- vii. hx4700 for the iPAQ hx4700,
- viii. fic-gta01 for the neo1973 phone;

You may also check

<http://cgit.openembedded.org/cgit.cgi/openembedded/tree/conf/machine?h=stable/2009>.

(c) **Start building.** Use

```
# set environment variables
source source-me.txt
#Go to the OE tree
cd ${OETREE}/openembedded
#Make sure it's up to date
git pull --rebase
#Start building
# you can specify machine on the cmdline:
MACHINE=yourmachine bitbake base-image ; MACHINE=yourmachine bitbake console-image x11-image
# If you have set it in local.conf you can do:
bitbake base-image ; bitbake console-image x11-image
```

Building for a different machine or C library is just a matter of changing the MACHINE= or ANGSTROMLIBC statement in local.conf to a new value. There is ABSOLUTELY no need for using different directories for that; Angstrom takes care of all the details, it was specifically designed for this.

Part IV

The Ångström System

CHAPTER 9

Introduction

THE *Ångström system*¹ is a Linux distribution (distro) for embedded devices (PDAs, Beagleboards, Mobile Phones, *etc.*). The Ångström community was started by a group of people who worked on the OpenEmbedded, OpenZaurus and OpenSimpad projects. They aim to create a stable, user friendly linux distribution for embedded devices.

Using Linux on an embedded device is an interesting thing. Users of such devices are often unsatisfied by the bad quality of the built-in OS'es and softwares on their embedded devices. Or a Linux *aficionados* is always unhappy to use something else than an UNIX-based system. The advantage of UNIX-based systems is well-known, and does not enter in the scope of this booklet. For these reasons, there are now Linux-based distros for embedded devices.

¹And not *OpenEmbedded Ångström*!

Some info comes from [5].

10.1 Introduction

As any modern distribution, Ångström is fully package-based. However, as interaction with the device during initial setup phase is difficult, Ångström is bootstrapped using an “image,” which is essentially a set of core packages already merged into archive or filesystem image. This image is installed using device-specific means, and provides basic Ångström functionality.

Adhering with the Ångström’s aim of flexibility and best practices of Linux system management, the images provide only core packages, allowing users to customize system to their needs by easily installing any required software from a wealth of Ångström’s feeds. However, as a convenience to users, different kinds of images are provided, for example, with (core packages of) different GUI environments pre-installed.

10.2 Core Principle

The *packaging system* was firstly based on ipkg (Itsy Packaging system), which was developed a long time ago for the Itsy handheld project, by Compaq. The original ipkg may¹ have been developed by Kernel Concepts (<http://www.kernelconcepts.de>). For example, its `.conf` files are stored in `/etc/ipkg/`. When that project closed down and <http://www.handhelds.org> came to be, ipkg was ported to the ‘Familiar’ system, running on the iPAQ hx4700. opkg appears to have been developed by OpenedHand Ltd. (<http://www.openedhand.com>.) The home of opkg is <http://opkg.googlecode.com>. The preconfigured feeds are located at `/etc/opkg`, and, according to [?], opkg is replacing ipkg, for different reasons; opkg has the following advantages:

- maintained, when ipkg is not,
- two companies behind it,

¹According to a comment in `src/opkg-frontend.c` in `opkg-0.1.7`.

- GPG signed packages and feeds.

Consequently, we shall speak only about opkg here.

The feeds for the 2007 image are located at

<http://www.angstrom-distribution.org/feeds/2007/>.

10.3 Commands

- To **look for a given package**, you may have a look at

`http://www.angstrom-distribution.org/repo/`

if you do not have an Internet access on your device,

- To **update the list of the packages** which is on your device, you could use

`opkg update`

- To **automatically upgrade every package** which needs to be upgraded on your device, you could use

`opkg upgrade`

- To **see the log file** of ipkg, you may look in

`/var/log/opkgupgrade.log`

- To **look for a package** `packagename`, you could use

`opkg search packagename`

(Regexps are also accepted),

- To **look for what is available as packages**, you could use

`opkg list`

- Once you know the name of the package you want to install, such as `packagename`, you then use

`opkg install packagename`

to **install it**. If you have it on your disk, you can then use

`opkg install dir1/dir2/.../packagename.ipk`

Be careful with dependencies,

- To **remove a package**, you can use

`opkg remove packagename`

If you want all its dependencies to be removed too, you then use

`opkg remove --recursive packagename`

being very careful.

10.4 Selecting Packages

As with any Linux distro, there are oftentimes different packages available to perform some given task. However, they often require different levels of resources (e.g. command line mail vs. GUI, command line mp3 playback vs. XMMS); the key thing with Ångström is whether you have opted for any GUI support at all (GPE, Opie or Qtopia) or whether you are strictly using command line. The key therefore is to read the package description and do not use packages with the word "opie" in them when you are GPE based and *vice-versa*!

10.5 Format of Packages

The software packages are stored in files whose name ends by `.ipk`; this is a compressed format, containing files to be installed as well as metadata and support scripts. Actually, the `.ipk` format is the *de facto* package format for Embedded Linux, and many other distros use it for their packages too. However, packages from different systems are not compatible. In particular, Ångström maintainers cannot guarantee system stability if packages which do not come from the official feeds are used.

10.6 Switch from Console Image to a X Server

If you are using a Console Image, you may install, once you have updated your lists of packages, `xserver-kdrive`, or `xserver-kdrive-imageon` (for Zaurus C7xo image users). Next, install `task-base-extended`, `angstrom-x11-base-depends`, `angstrom-gpe-task-base`, `angstrom-gpe-task-settings`, `libesd0`. It will give you a fully working X GUI and a base GPE environment.

11.1 The User

ONCE you have installed Ångström, you can modify your owner's info by editing `/etc/gpe/gpe-ownerinfo.data`

11.2 Checking the Version

You can check the current Ångström version you are running by reading the content of (the file):

```
/etc/angstrom-version
```

You can also use

```
uname -a
```

just like you would do on every normal UNIX station.

11.3 Global Networking

Some info comes from [5].

One of the first things you want to do after installing an Ångström release is to connect to Ångström's website and get the latest updates for security and important bug fixes. If you connect to the Internet "directly" (for example, via GPRS) or via a dedicated router (for example, using WiFi or Ethernet), you usually do not need to do additional configuration "on the other end," assuming your GPRS account is enabled and router already setup to serve other computers.

11.3.1 Basic Info

You may use, to

- List available interfaces:

```
ifconfig
```

- **Bring interface `interfacename` up:**

```
ifconfig interfacename up
```

or

```
ifup interfacename
```

- **Bring interface `interfacename` down:**

```
ifconfig interfacename down
```

or

```
ifdown interfacename
```

11.3.2 With USB

However, many people with conventional PDA devices will connect using USB to the desktop or laptop computer. In this scenario, your host computer will serve as a router for your Ångström device, and so must be configured accordingly: you must enable IP forwarding and NAT on it. Please consult your Linux distribution manual on how to make such changes permanent, to be able to connect the device to the Internet without manual setup in the future. We here assume that you are using a Linux server. If you are using a Windows one, you need to enable ICS(Internet Connection Sharing) to achieve the similar functionality. If you are already using ICS for a different interface than the one you projected to work with, consider the use of a simple proxy such as AnalogX's, for giving other cards access to the Internet. It is due to the fact that ICS can only deal with a couple (of two) devices.

11.3.2.1 On the Server

To *activate NAT*, you could do

```
iptables -t nat -A POSTROUTING -o eth0 -j MASQUERADE
```

assuming `eth0` is your external interface.

To *activate IP forwarding*, you then edit `/etc/sysctl.conf`, adding

```
net.ipv4.ip_forward = 1
```

to it, or replacing

```
net.ipv4.ip_forward = 0
```

by

```
net.ipv4.ip_forward = 1
```

if

```
net.ipv4.ip_forward = 0
```

is already there. You can then reload the config using

```
sysctl -p /etc/sysctl.conf
```

which should show you the line

```
net.ipv4.ip_forward = 1
```

(there could be other lines before, evidently).

You then need to load the modules `usbnet`, `cdc_ether` and `g_ether` (the last one being done if your host is also a device). You also need to add an entry to `/etc/network/interfaces` like

```
iface usb0 inet static
    address 192.168.129.1
    network 192.168.129.0
    netmask 255.255.255.0
    broadcast 192.168.129.255
```

if you are running Debian, or

```
config_usb0=( "192.168.129.1" )
```

to `/etc/conf.d/net` if you are using Gentoo, or even create a file

```
/etc/sysconfig/network/ifcfg-usb0
```

with

```
BOOTPROTO='static'
STARTMODE='auto'
USERCONTROL='yes'
NAME='Sharp Zaurus'
IPADDR='192.168.129.1'
BROADCAST='192.168.129.255'
NETMASK='255.255.255.0'
NETWORK='192.168.129.0'
PREFIXLEN=''
```

if you use SuSE.

11.3.2.2 On the Slave

On the slave (the computer running Ångström), you will then

```
modprobe g_ether
```

(if the command

```
lsmod | grep g_ether
```

gives nothing as result). Consequently, using then

```
ifconfig -a
```

should display some devices, but at least `usb0`. If necessary, you may run

```
ifup usb0
```

(if `usb0` is already there, no need¹ for it). You can then modify the IP stuff with either the GUI of your front-end (X11, GPE, ...), or by appending

```
iface usb0 inet static
    pre-up modprobe g_ether
    address 192.168.129.201
    netmask 255.255.255.0
    gateway 192.168.129.1
    post-down rmmmod g_ether
```

for example, to your `/etc/network/interfaces`.

11.3.3 With Bluetooth

Ångström uses the standard 2.6 kernel's Bluetooth modules (which were derived from <http://www.bluez.org/>). Userspace commands used to control/access Bluetooth hardware are `hciconfig`, `hcitool`, `rfcomm`, `l2ping` and other ones. (It is also implemented in GUIs.) Before establishing a Bluetooth connection with another computer, either for `rfcomm` or `pand`, it is necessary to pair the two. Bluetooth uses a PIN, or password, for incoming pairing requests. This one is set in the `/etc/bluetooth/pin` file, and for outgoing requests by the utility "passkey-agent."

There are two ways to make a network using Bluetooth: one is to use point-to-point protocol (PPP) over the `rfcomm` (serial-like link); the other is to use PAN. This is a very brief summary to give you an understanding of the processes involved:

1. **PPP** over `rfcomm` was previously popular with PDAs like Palms and some Windows Mobile/PocketPC/WinCE devices. It is not so efficient, but is useful if you are connecting the device to a Windows computer. On the Ångström device you need to create the appropriate files in `/etc/ppp` and then trigger the PPP connection using the command

```
pppd call XXX
```

(XXX being the profile); this then results in a `ppp0` device appearing.

If the called device is correctly set up, the `ppp0` device will end up with the correct IP address and default route, and the local DNS resolver will probably also be set correctly, otherwise use

```
ifconfig ppp0
route add default gw x.x.x.x
```

to tweak settings,

2. **PAN/PAND** is best for making a Linux-to-Linux connection. Simply run

```
pand -listen
```

on one end, and

¹Note that issuing `ifup usb0` would do nothing, in this particular case: it would not duplicate a device!

```
pand -connect xx:xx:xx:xx:xx:xx
```

on the other where the xx's are the parts of the MAC address of the other device (use

```
hciconfig -a
```

to find out the MAC address). When connected, use

```
ifconfig bnep0
```

to set the IP address. Use

```
route add
```

to make routes (*e.g.*

```
route add default gw 192.168.129.1
```

), just as with any other network connection. You might also need to tweak `/etc/resolv.conf` on the Ångström device so it can resolve names into IP addresses. It should be possible to create a `bnep0` entry in `/etc/network/interfaces` for this.

In both cases, it is likely that you are using the other end of the Bluetooth connection as a gateway to allow the Ångström device to access the internet (*e.g.* access mail, browse the web, install from software feeds). If the remote box is running Linux you may want to set up masquerading on its external/outbound interface and thus allow the Ångström device to access hosts and networks other than the gateway. Do not forget neither to turn on `ipv4forwarding` just as in Subsubsection [11.3.2.1](#), p. 36. The equivalent in Windows is “Internet Connection Sharing,” accessed through the properties for the external interface.

11.3.4 With WiFi

11.3.4.1 Preliminaries

On some devices, you may need to load specific modules to allow WiFi. It depends on the chipsets.

- For the `hx4700`, you need to type

```
modprobe hx4700-acx
modprobe acx debug=0
```

in a terminal before being able to use WiFi. If you do not want to `modprobe` specific modules manually, you can add them in `/etc/modules`, just like in every normal UNIX system.

11.3.4.2 Commands

Commands for WiFi are supposed to be known (`iwconfig`, `iwlist`, ...), as they are universal. Here are some basic commands for you, if you are too lazy to have a look at man pages:

- **List networks:**

```
iwlist interface scan
```

where `scan` can be replaced by `scanning` and where `interface` is often `wlan0`,

- **Connect to network** with a ESSID `essidname`:

```
iwconfig interface essid essidname
```

As in the other methods, you are also able to **bring up the interface** issuing

```
ifup interface
```

and, to bring it down,

```
ifdown interface
```

where `interface` is often `wlan0` (it can be verified using `ifconfig`). If `iwconfig` and related commands are missing (your `$PATH` being correct, or after having tried with `/sbin/iwconfig`), be sure to install the `wireless-tools` package.

For WEP/WPA/PSK, you need to edit `/etc/network/interfaces`, as explained in the following lines.

11.3.4.3 WEP

Here is an example for *WEP encryption*:

```
iface wlan0 inet dhcp
    wireless_mode managed
    wireless_essid youressid
    wireless_key yourwepkey
```

11.3.4.4 WPA

Here is an example for *WPA/PSK encryption*:

```
iface wlan0 inet dhcp
# start wpa_supplicant
    wpa-conf /etc/wpa_supplicant.conf
    wpa-driver hostap
```

If `wpa_supplicant.conf` does not exist in `/etc`, create one with

```

/etc/wp_supplicant.conf
ctrl_interface=/var/run/wpa_supplicant
ctrl_interface_group=0
eapol_version=1
ap_scan=1
fast_reauth=1
network={
    ssid="(your SSID)"
    proto=WPA
    pairwise=TKIP
    psk= (quoted text or hexadecimal number)
    priority=1
}

```

(You may have a look at http://linux.die.net/man/5/wpa_supplicant.conf.) You also need to install the package `wpa_supplicant`.

11.3.4.5 Drivers

There are roughly two different drivers:

1. `hostap`: supports WEP and WPA,
2. `acx`: supports WEP.

11.3.5 Firewall

Just like in every normal Linux distro, you may use the following trivial firewall:

```

iptables -P OUTPUT ACCEPT
iptables -P INPUT DROP
iptables -A INPUT -m state --state ESTABLISHED,RELATED -j ACCEPT

```

To make this happen on boot-up, you may create a script with these lines, put it into `/etc/init.d/firewall`, and make soft links to the script from the `rc3.d` and `rc5.d` directories.

11.4 Errors You Could Encounter

It is possible that you *encounter different errors*, such as, in the console:

```
xxx: command not found.
```

In this case, please check that `/sbin/` is in the environment variables. If it is not the case, simply add it, or always use `/sbin/` before each app, *i.e.*

```
/sbin/modprobe mymodule
```

or

```
/sbin/ifconfig myadapter
```

If you do not want to do this every time you want to use such a command, you may simply add `sbin` to `$PATH` (it is actually only necessary if you are using a live ram disk):

```
PATH=$PATH:/sbin
export PATH
```

CHAPTER 12

Getting More Help

THE objective of this booklet was to provide an easy way to find fresh info about Ångström. It is particularly difficult to find *recent* info on such a subject when the community is not really big. Fortunately, despite being a small community, users are active. The principal concepts are evoked here, and feel free to send an e-mail to any contributor (*and* to me) if there are any interesting things to say which could be nice to put here. That being said, there are other websites which you can find any other info on. For example, one can find some interesting information in [5]. There is also the principal <http://www.angstrom-distribution.org/> website, and the mailinglist (see <http://www.angstrom-distribution.org/contact> and <http://lists.linuxtogo.org/pipermail/angstrom-distro-users/> for this).

Index

.cpio.gz, [20](#)
.exe, [20](#)
.ext2, [20](#)
.ext2.bz2, [20](#)
.img, [20](#)
.img.bz2, [20](#)
.jffs2, [20](#)
.summary.jffs2, [20](#)
.tar.bz2, [20](#)
.tar.gz, [20](#)

base-image, [19](#)
bootbundle, [14](#)
bootmanager, [20](#)
BugZilla, [26](#)

console-image, [19](#)

HaRET, [13](#), [14](#)

i18n, [24](#)
initramfs.cpio.gz, [13](#), [17](#)
Initrd, *see* initramfs.cpio.gz
initrd, *see* initramfs.cpio.gz

kexecboot, [15](#)

l19n, [24](#)
LiveRam Disk, [10](#), [11](#), [20](#)
Loopback image, [8](#)

minimal-gpe-image, [19](#)

Startup script, *see* startup.txt.bootimage
startup.txt.bootimage, [13](#), [14](#)

x11-gpe-image, [19](#)
x11-image, [19](#)
x11-office-image, [19](#)
x11-pilico-image, [19](#)
zImage, [13](#), [14](#)

Bibliography

- [1] BITBAKE, *BitBake (Example 4.7)*, 2010. <http://bitbake.berlios.de/manual/ch04s02.html#id870480>.
- [2] Y. BUSHMELEV, *Picasa Albums Web – Jay*. <http://picasaweb.google.ru/yuri.bushmelev>, 2009.
- [3] C. COMMONS, *Creative Commons – Attribution-Share Alike 3.0 Unported*, 2009. <http://creativecommons.org/licenses/by-sa/3.0/>.
- [4] —, *Creative Commons Legal Code: BY-SA*, 2009. <http://creativecommons.org/licenses/by-sa/3.0/legalcode>.
- [5] LINUXTOGO, *Ångström Manual*, 2009. <http://www.linuxtogo.org/gowiki/AngstromManual>.
- [6] —, *WinCeQuickInstall*, 2009. <http://linuxtogo.org/gowiki/WinCeQuickInstall>.
- [7] L. MERCIADRI, *Using Linux on a Handheld Device: an Obstacle Course?* 2009.
- [8] OPENEMBEDDED, *Building Ångström — The Ångström Distribution*, 2006. <http://www.angstrom-distribution.org/building-angstrom>.
- [9] —, *OEandYourDistro - OpenEmbedded*, 2010. <http://wiki.openembedded.org/index.php/OEandYourDistro>.
- [10] T. S. PRESS, *Chapter 3 – How Linux Boots*, 2004. http://nostarch.com/download/howlinuxworks_ch3.pdf.